




JHR GATE | IHOME
Model Number | S95-PY2119



JHR GATE | IHOME
Model Number | S95-PY2122





JHR GATE | IHOME
Model Number | S95-DK0113





JHR GATE | IHOME
Model Number | S95-DK0115

Sliding Gate Post for Choice



JHR GATE | IHOME
Model Number | S95-PY2120



JHR GATE | IHOME
Model Number | S95-PY2123





JHR GATE | IHOME
Model Number | S95-DK0119



JHR GATE | IHOME
Model Number | S95-DK0120

Notes For Sliding Gate




JHR GATE | IHOME
Model Number | S95-PY2121



JHR GATE | IHOME
Model Number | S95-PY2124



JHR GATE | IHOME
Model Number | S95-DK0121



JHR GATE | IHOME
Model Number | S95-DK0125

Installation Tips:

1. Determine Installation Positions: Based on the gate length, mark the installation positions for the gate posts, ground track, and set reference lines according to the drawing.
2. Construct Foundation: Within the gate operating range, pour reinforced concrete foundation to install the track by screws, ensuring it remains level and straight.
3. Secure Gate Posts: Use expansion bolts to fix the main post and receiving post onto the concrete foundation. Verify the positioning and spacing between the posts and track.
4. Install Gate Body & Stopper: Vertically guide the gate body into the main post via rollers and track. Secure the gate stopper at a safe position. Conduct repeated push-pull tests to confirm smooth operation, then tighten all fixing bolts with a wrench.
5. Install Motor & Electrical Connections: Measure the motor mounting height based on the rack position. Construct a motor base and embed the motor cable within it. Complete wiring and conduct repeated tests until the gate opens and closes properly.




IHOME COURTYARD
SLIDING GATES
95SYS

CUSTOMIZED MADE
FACTORY DIRECT
QUALITY ASSURED







• Product images shown in this catalog are for style reference only. Actual products may vary by specification. Please contact us for detailed styles and dimensions.
 • Due to printing limitations, colors of product images may differ from the actual products. Please refer to the physical product.
 • Producing one ton of paper consumes nine trees. Please help protect the environment and conserve resources – it starts with you and me.
 • Our company reserves the right of final interpretation of all content in this catalog.




JHR GATE | IHOME
Model Number | S95-PY2113




JHR GATE | IHOME
Model Number | S95-PY2116




JHR GATE | IHOME
Model Number | S95-PY2114



JHR GATE | IHOME
Model Number | S95-PY2117




JHR GATE | IHOME
Model Number | S95-PY2115




JHR GATE | IHOME
Model Number | S95-PY2118



Color Options



Various Styles



Sliding Gate Wheels



Gate Motor

- Stable, long-term and easy maintenance.
- Easy installation, requires flat ground.
- Industrial aluminum: strong, rust-proof, weather-resistant.

- Custom wheels: stable, flexible, high load capacity.
- Durable tight structure with mortise-tenon assembly.
- Custom sizes & styles available.

PROFESSIONAL MANUFACTURER of Premium Aluminum Products

Gates | Fences | Pergolas | Carports | Gazebos | Entry Doors



☎ 400-885-6385
 📞 +86-135 4366 9385
 📠 +86-757 8378 7525
 ✉ sales@jhrtech.com
 🌐 www.jhrtech.com (CN)
 🌐 www.jhrgate.com (EN)



CN Web



EN Web